

Electrode-electrolyte interface

X23 (2023) — English translation

Electrolytes are substances that conduct electric current due to dissociation into ions. Their electrical conductivity is determined by the mobility of positively and negatively charged ions. A system consisting of a container with an electrolyte and a solid membrane immersed in it is called an electrode-electrolyte interface. This system has unique electrical properties, which are widely used in the creation of lithium-ion batteries and ionistors (supercapacitors). In this problem we will consider the basic properties of the electrode-electrolyte interface. The electrolyte will be a solution of table salt NaCl in water. Throughout the problem, we will consider this solution as a suspension of Na^+ and Cl^- ions in a liquid dielectric. The membrane in the problem is the surface of the steel piston and the spout of the syringe; throughout the entire problem, we will consider steel to be an ideal conductor, the conductivity of which is much greater than the conductivity of the electrolyte. The following constants may be useful for solving the problem:

Elementary charge $e = 1.602 \cdot 10^{-19}$ C Avogadro's number $N_A = 6.02 \cdot 10^{23}$ Molar mass $\text{Na}\mu_{\text{Na}} = 23.0$ g/mol Molar mass $\text{Cl}\mu_{\text{Cl}} = 35.4$ g/mol Molar mass $\text{H}\mu_{\text{H}} = 1.0$ g/mol Molar mass $\text{O}\mu_{\text{O}} = 16.0$ g/mol

Attention! The problem does not require error estimation. Attention! Use a personal lamp to illuminate your work area. Equipment: Steel syringe. Two alligator-crocodile wires. Generator with wire for generator. Oscilloscope with two oscilloscope leads. Three plastic containers. Disposable spoon Plastic syringe for preparing solutions Resistor $R_0 = 22.0$ Ohm. 1 l water for preparing solutions (not drinking), bottles are marked with a blue cross. 150 g salt inside the Libra container. Ruler (from the equipment of problem E2).




Figure 1: Figure 1.

Part A. Preparatory measurements.

A1 Measure the inner diameter of the syringe D_0 and the distance L_0 between marks 0 and 20 . **0.02**

Within the framework of the problem, we will denote the concentration of a salt solution in water by the dimensionless quantity $c = \frac{m}{m}$, where m is the mass of the initially taken clean water, m is the mass of salt powder added to clean water to obtain a solution. Prepare a salt solution with a concentration of $c \approx 0.07$. Draw this solution into the syringe, and to avoid the formation of excess bubbles inside the syringe, move the plunger slowly. When taking measurements, you need to hold the syringe in some fixed position (for example, standing on the piston stem) so that the configuration of the bubbles that form one way or another is the same.

Bubbles in the solution inside the syringe caused by the plunger moving too quickly.




Figure 2: Figure 2.

The solution inside the syringe is free of bubbles.




Figure 3: Figure 3.

Throughout the task we will be studying the electrical properties of the electrolyte solution inside the syringe, so we should use the circuit shown in the figure. Attention! Under no circumstances should the oscilloscope wires and generator wires directly touch the glass syringe if you have already filled it with water.




Figure 4: Figure 4.

Use the generator in mode $V_{pp} = 1.00$ V, where V_{pp} is the voltage difference between peaks (double signal amplitude). Be sure to remember to turn on the signal at the output of the generator: Generator AKIP-3408 – “Output” button Generator AKIP-3407 – button “Output” Generator UTG2025 – button “CH1” or “CH2” depending on which channel you use. Generator UTG9020 – automatically turned on. The current in our system can be significantly noisy (this is the so-called electrochemical noise, which is symmetrical in the positive and negative regions), so any voltage amplitudes should be measured in the Cursor mode in manual mode and not rely on the Measure module. To measure the voltage on the syringe, be sure to obtain it as a signal using the Math module in subtraction mode. To work with the Math module: Click the “Math” button. Click the Math button a second time, or click the button corresponding to ExpandOper. In order for the Math channel to be equal to CH1-CH2, there must be the following correspondence: “Formula” - “A-B” “Action” - “On” “Source A” - “CH1” “Source B” - “CH2” When everything is configured, and you are in another window, for example Cursor, to change the scale of the Math channel, steps follow 1 and 2, and then adjust the scale with the same knob that changes the scale of ordinary channels (Vertical Scale). For CH1 and CH2, check that the Probe setting matches the probe mode that uses the probe. If it doesn’t match,

adjust it.

When everything is set up and you are in another window, for example Cursor, to change the scale of the Math channel, follow steps 1 and 2, and then adjust the scale with the same knob that changes the scale of regular channels (Vertical Scale).

Oscilloscope probe (do not use it to output the signal from the generator).

The probe mode switch is highlighted in red.

Green highlighted contact "Ground"

The "Signal" contact is highlighted in blue.




Figure 5: Figure 5.

At frequency $f \approx 50$ kHz the phase difference between the current through the syringe and the voltage across it is practically zero. This means that at this frequency the electrolyte solution inside the syringe behaves like a resistance R . It is expected that this resistance changes as the length L of the electrolyte inside the syringe changes.

A2	Make resistance measurements R corresponding to the positions of the syringe $V = 2, 4, \dots, 20$.	0.40
-----------	--	-------------

A3	Plot R versus V . Draw a smoothing straight line $R = R_1 + \alpha_1 V$. Calculate the values of parameters R_1 and α_1 .	0.40
-----------	---	-------------

Part B. Volumetric effects.

Prepare 4 different salt solutions with concentrations $0.07 \leq c \leq 0.20$. When changing the concentration of the solution inside the syringe, be sure to rinse it with clean water.

B1	For each of the prepared solutions, carry out a series of 4-ex measurements R from V .	0.80
-----------	--	-------------

B2 Using least squares method for each solution, calculate the parameters R_1 and α_1 by analogy with point **3**. Present the results in the form of a table. **0.12**

The theoretical description of the results obtained follows from the standard problem of conductivity of the second kind: consider the action of an electric field on a charged particle in a viscous medium. Let the mass of the particle be m and the charge q , and if the particle moves, then the force of viscous friction $F = -kv$ acts on it.

B3 An external constant field E is created in the medium. What is the steady-state velocity of the particle v ? Write the answer using E, k, q . **0.06**

The viscosity coefficient k , with which we model the movement of ions in a solution, is associated not only with viscosity, but also with the electrical properties of water and depends on the concentration of ions:

$$k \propto n^\alpha,$$

where α is an unknown degree, the same for ions Na^+ and Cl^- . Let an electrically neutral solution of table salt be inside a cylindrical vessel with conducting electrode bases and non-conducting walls. The area of the bases is S , the distance between them is L . We will assume that ions Na^+ and Cl^- in any quantity can appear and disappear as a result of chemical reactions with electrodes. The ion charges coincide in absolute value with the elementary charge $e = 1.602 \cdot 10^{-19}$ C.




Figure 6: Figure 6.

Let us denote by n the concentration of sodium ions, by k_{Na^+} and k_{Cl^-} the viscosity coefficients for sodium and chlorine ions, respectively.

B4 What is the steady-state current I if a potential difference U is applied to the electrodes? Neglect any surface effects (eg contact potential difference and contact resistance). Write your answer using $n, S, L, e, k_{\text{Na}^+}, k_{\text{Cl}^-}$ and U . **0.15**

In practice, the study of direct current is associated with the following difficulty: due to chemical reactions, the bases of the cylinder are gradually destroyed/covered with a film. Therefore, it is much more convenient to study conductivity with alternating current. Let us carry out a theoretical analysis within the framework of our model.

B5 Let a potential difference $U(t) = U \cos \omega t$ be applied to the bases, how will the current $I(t)$ depend on time? Again, ignore any surface effects. Write your answer using $n, S, L, e, \omega, m_{\text{Na}^+}, m_{\text{Cl}^-}, k_{\text{Na}^+}, k_{\text{Cl}^-}, U$ and t . **0.65**

B6 Now let's take into account surface effects in the form of a resistor R_p , which is connected in series to the solution. Write down the formula for the impedance $\tilde{Z}(\omega)$ of a system consisting of a solution NaCl and a vessel. Write your answer using $n, S, L, e, m_{\text{Na}^+}, m_{\text{Cl}^-}, \omega, k_{\text{Na}^+}, k_{\text{Cl}^-}$ and R_p . **0.25**

B7 What is the theoretical system impedance $\tilde{Z}$ if the phase difference between the voltages is negligible? Express your answer in terms of $n, S, L, e, m_{\text{Na}^+}, k_{\text{Cl}^-}$ and R_p . **0.10**

The case considered in **B8** obviously corresponds to the measurements made within the framework of points **A2** and **B1**.

B8 Using the linearized graph of α_1 against c obtain the value α . **0.40**

B9 Obtain the theoretical dependence $|\tilde{Z}|^2(\omega)$ in the approximation $\omega m_{\text{Na}^+} \gg k_{\text{Na}^+}, \omega m_{\text{Cl}^-} \gg k_{\text{Cl}^-}$. Write your answer using $n, S, L, e, m_{\text{Na}^+}, m_{\text{Cl}^-}, \omega, k_{\text{Na}^+}, k_{\text{Cl}^-}$ and R_p . **0.40**

B10 For a solution with salt concentration $c \approx 0.20$, measure the impedance modulus $|Z|$ versus frequency f . The series must consist of at least 7 different f in the range $500 \text{ kHz} \leq f \leq 10 \text{ MHz}$. **0.35**

B11 Plot a linearized graph of $|Z|$ versus f . From the graph, determine the experimental value $\mu_{\text{eff}} = \frac{\mu_{\text{Na}^+} \mu_{\text{Cl}^-}}{\mu_{\text{Na}^+} + \mu_{\text{Cl}^-}}$. **0.50**

The μ_{eff} obtained in the experiment differs significantly from the theoretical value. This difference can be explained by the fact that water molecules, which have a dipole moment, are attracted to the ions (solvate them) and move with them. Let us denote the number of water molecules moving together with an ion of any type by N . In this case, instead of μ_{Na^+} when calculating, you need to use $\mu_{\text{Na}^+} + N\mu_{\text{H}_2\text{O}}$ and instead of μ_{Cl^-} you need to use $\mu_{\text{Cl}^-} + N\mu_{\text{H}_2\text{O}}$.

B12 Determine N based on your experimental data. **0.15**

Part C. Surface effects.

The electrolyte syringe also has a capacity that cannot be predicted by volumetric theory. This capacity begins to affect itself at low frequencies of the signal supplied to the ends of the syringe. The capacitance of the electrode surface-electrolyte system is due to the fact that ions (like any charged particles) are attracted to the metal surface and form the so-called. electrical double layer. Thus, a unit of surface contact between the metal and the electrolyte has a capacity of $\sigma = \frac{dC}{dS}$, where C is the capacitance of a surface with an area of S . Fill the syringe with a solution with a salt concentration of $c \approx 0.20$.

C1 In the frequency range $5 \text{ Hz} \leq f \leq 1 \text{ kHz}$, measure the syringe impedance modulus $|\tilde{Z}|$ and the time Δt by which the current peak precedes the voltage peak. Take at least 15 measurements. **1.50**

For analyzing an electrical circuit, the so-called Nyquist diagram - dependence of $\Im m \tilde{Z}$ on

$\Re\tilde{Z}$. In our case, we can assume that volumetric effects are reduced to a resistor with resistance R_2 , and surface effects are expressed from measurements as follows: $\tilde{Z}_p = \tilde{Z} - R_2$.

C2	Based on your data, plot a Nyquist plot of $\Im\tilde{Z}_p$ from $\Re\tilde{Z}_p$ for surface effects. Indicate on the diagram in the form of an arrow the direction of transition from point to point, corresponding to the increase ω .	0.60
-----------	--	-------------

C3	Qualitatively draw the Nyquist diagram for a parallel-plate capacitor.	0.10
-----------	--	-------------

The previously described model of the formation of capacitance C at the contact surface of the electrolyte and metal, if this surface is flat, should be reduced to the fact that surface effects have a Nyquist diagram, like a capacitor, but experiment contradicts this thesis. While analyzing a similar problem, the Danish chemist Robert de Levy proposed a model of a rough metal surface, which turned out to be very fruitful for describing the electrical properties of electrode-electrolyte interfaces.




Figure 7: Figure 7.

Let us imagine the surface of the conductor as a plane on which cylinders of height l and radius r stand. The density of the cylinders can be described by the surface density $\xi = \frac{dN}{dS}$, where N is the number of cylinders in the area S . In this case, per cylinder there is $1/\xi$ area of the electrolyte around it. In this case, the unit height of the cylinder has a certain capacity C_l and the unit height of the electrolyte per cylinder has a certain resistance R_l . To shorten the entries, let us denote the specific resistance of the electrolyte as ρ .

C4	Write down the expressions for C_l and R_l in terms of r, σ, ρ and ξ .	0.20
-----------	--	-------------




Figure 8: Figure 8.

C5 Write the complex current $\tilde{I}(x)$ in terms of the derivative of the complex potential $\frac{d\tilde{\varphi}(x)}{dx}$ and R_l . **0.10**

C6 Relate the derivative of the complex current $\frac{d\tilde{I}(x)}{dx}$ and the complex potential $\tilde{\varphi}(x)$ via C_l . **0.10**

Note 1: To find two numbers a such that $a^2 = \sqrt{i}$ you can use Euler's formula. Note 2: $\cos x = \cosh ix$, $i \sin x = \sinh ix$, $i \tan x = \tanh ix$, $\tanh(x \pm y) = \frac{\tanh x \pm \tanh y}{1 \pm \tanh x \tanh y}$.

C7 Show that $\tilde{I}(0) = 0$. **0.20**

C8 Solve the system of differential equations obtained in steps **C5** and **C6** and obtain the impedance $\tilde{Z}(\omega)$ of one cylinder and the electrolyte surrounding it. Neglect the capacity of the base of the cylinder and the capacity of the flat surface on which the cylinders stand. Express your answer using C_l , R_l , l and ω . **1.25**

C9 Obtain the impedance $\tilde{Z}(\omega)$ to the approximation $\sqrt{\omega C_l R_l l^2} \gg 1$. Express your answer using C_l , R_l , l and ω . The following theoretical points are also solved in this approximation. **0.20**

C10 What is the impedance $\tilde{Z}_p(\omega)$ of one surface of the cylinder in contact with the electrolyte? Surface area S . Express your answer using r , σ , ρ , ξ , S and ω . Draw a qualitative Nyquist diagram $\tilde{Z}_p(\omega)$. The theoretical and experimental Nyquist diagrams should be identical in shape, but some of their characteristics may differ slightly. **0.20**

C11 Plot a linearized graph of $|\tilde{Z}_p|$ versus ω . **0.70**

We will assume that $\xi = 40 \frac{1}{\text{mm}^2}$, $r = 0.6 \text{ um}$. Consider the contact area of the syringe nose with the electrolyte to be 5.5 times less than the area of the internal cross-section of the syringe.

C12 Define σ .

0.10

Source: <https://pho.rs/p/3156>